

## Door Insert Installation

All inserts are shipped KD with assembled screens. Grommet holes for operator crank must be installed on site. Grommets provided.

### INSTALLATION INSTRUCTIONS

Caulk opening (1) and mount sill first (2). Screws are not necessary, the strip hardware will hold the sill down and screw holes may cause leaking. Install strip hardware by screwing through hanger hardware. Holes are prepunched between every other clip (3). Caulk header top and install with screws from underside upward (4). Install operator with screws provided in holes pre-drilled (5). Caulk around entire perimeter, inside and outside (6), paying special attention to extrusion joints. Install louvers into clips (see louver installation page). Position the screen on inside of door and mark grommet location. Install grommets. Fasten screen to door with screws provided (7). Insert crank handle into operator (8). Wipe down all excess caulk. Test insert for seal and operation.

